


BAMW2330-P Illustrated Part Breakdown



Model: BAMW2330-P

No	Description	Qty
P01	door (with inlaids)	1
P02	door window	1
P03	fuse socket	1
P04	capacitor holder	1
P05	fan shroud	1
P06	fan blade	1
P07	door frame	1
P08	choke cover	1
P09	washer	1
P10	shaft	1
P11	roller ring	1
P12	glass tray	1
P13	splash shield	1
P14	upper hinge	1
P16	cavity	1
P17	label	1
P18	outer enclosure	1
P19	heater holder	1
P20	power cord holder	1
P21	lamp socket	1
P22	air duct	1
P23	microswitch mounting	1
P24	shockproof rubber	1
P26	foot	4
P27	base plate	1
P28	lower hinge	1
P29	keyboard (with inlaids)	1
P30	stainless flake	1
P31	lever	1
P32	button spring	1
P33	button	1
P35	tube holder	1
P36	heat barrier	1
P37	thermostat holder	1
P38	key pads	1
P39	knob	1
P41	metal rack	1
P105	layering	1
P106	button cover	1
C01	h.v. fuse	1
C02	h.v. diode	1
C03	h.v. capacitor	1
C04	wave filter	1
C05	fan motor	1
C06	lamp	1

No	Description	Qty
C07	thermostat	1
C08	magnetron	1
C09	microswitch	1
C10	microswitch	1
C11	microswitch	1
C12	transformer	1
C13	wiring harness	1
C14	power cord	1
C15	turntable motor	1
C17	p.c. board	1
C19	thermostat	1
C20	quartz tube	2
B01	upper foam cushion	1
B02	turntable cushion	1
B03	plastic bag	1
B04	manual	1
B05	protection film	1
B06	plastic bag	1
B07	lower cushion	1
B08	carton	1
B09	cardboard	1