

DW-0165-001

140410

A

B

C

D

E

借(通)用件登记

旧底图总号

底图总号


出图审查

日期

D

E

F



DW-0165-001			
W60A1A401P-AA0			
1			

DW-0165-001

8

A2 (594 × 420)

Dishwasher Model: W60B1A401P			
Code	Part no.	English Name	Quantity
1	DW-0092-226	External door	1
2	DW-0155-154	Panel stainless sheet	1
3	DW-0155-178	Program button	3
4	DW-0155-474	Panel adhesive	1
5	DW-0153-354	Rubber lamp cap	9
6	DW-0155-115	Control board holder	1
7	DW-0153-101	Control panel	1
8	DW-0001-027	Hinge assembly	1
9	208210000217	Inner door	1
10	10.0418.84	Detergent dispenser	1
11	DW-0001-346	Tub gasket	1
12	DW-0056-230	Tub bottom bitument	1
13	DW-0056-506	Plastic cover	1
14	DW-0001-427	Overflow float	1
15	DW-0001-118	Overflow holder	1
16	MS1-06ZB1-A025-80	Overflow microswitch	1
17	050.0-708	OTK500	1
18	DW-0001-024	Sump assembly	1
19	DW-0001-341	Block for draining pump	1
20	YTB25-2A(L)	Draining pump	1
21	DW-0001-330	Sump seal	1
22	DW-0001-170	Sump deflector	1
23	CWF2 50KF3950	Temperature sense organ	1
24	DW-0001-355	Seal for turbidity sensor	1
25	DW-0001-382	Overflow hose	2
26	DW-0001-131	Overflow launder	2
27	DW-0001-307	Screw for guide	8
28	DW-0001-127	Air breaker nut	1
29	DW-0005-127	Water breaker nut	1
30	DW-0001-141	Guide holder	4
31	DW-0001-140	Guide wheels	8
33	DW-0001-356	Guide holder seal	8
34	DW-0119-357	Inlet hose for flowmeter	1
35	SK-5420-07-2	Flowmeter	1
36	019.2-708	OTK192	2
37	DW-0005-358	Inlet hose for breaker	1
38	DW-0018-335	Seal for air breaker	1
39	DW-0006-387	Water breaker	1
40	DW-0056-227	Left side panel	1
41	DW-0001-237	Guide reinforce	2
42	GB/T 9601-202	/	12
43	DW-0001-336	Ruber tubbe for heater	1
44	038.1-708	OTK381	2
45	DW-0001-364	Heating	1
46	DW-0001-337	Inlet rubber duct for washing pump	1
47	039.6-708	OTK396	1
48	DW-0056-339	Motor damping rubber	2
49	DW-0056-218	Washing pump bracket	1
50	DW-0026-365-101	Main PCBA	1
51	DW-0041-191	PCB box	1
52	DW-0056-228	Right side panel	1
53	GH25A-2S01	Washing pump	1

can use 674006100000

54	036.1-708	OTK361	2
55	DW-0001-338	Outlet rubber duct for washing pump	1
56	DW-0001-351	Pressure hose	1
57	DW-0001-157	Hinge line	2
58	DW-0056-151	Adjustable foot	4
59	DW-0056-212	Foot rest	2
60	33290255	Water inlet valve	1
61	37610187	Pressure switch	1
62	DW-0002-303	Door spring	2
63	DW-0001-385	Air inlet	1
64	DW-0001-335	Seal for air breaker	1
65	017.5-708	OTK175	1
66	G004T13500	/	2
67	DW-0001-306	Door lock hook	1
68	DW-0001-134	Clasp holder	1
69	DW-0001-211	Support reinforce	2
70	DW-0164-020	Tub assembly	1
71	DNF06-Z(DFZF)	Power filter	1
72	DW-0056-505	Plastic base	1
73	DW-0056-327	damping tray for inner tub	2
74	DW-0001-362-L1W	Power cord	1
75	DW-0056-509	holder for water pipe	1
76	DW-0001-381	Draining hose	1
77	DW-0056-235	Pipe holder	1
78	PY-3	Inlet hose	1
79	DW-0056-508	lower cover of balance box	1
80	DW-0056-507	upper cover of balance box	1
81	DW-0005-411	Tub deadening	1
82	DW-0002-152	Top panel holder	2
83	DW-0095-175	Back roof	1
84	DW-0002-434	Rear bracket of top panel	1
85	DW-0095-174	Front roof	1
86	DW-0002-401	Tub top bitument	1
87	DW-0018-409	Tub backside bitument	1
88	DW-0001-232	Upper rear crosspiece	1
89	DW-0001-426	Pad for upper rear crosspiece	1
90	DW-0001-137	Pipe casing	1
91	DW-0001-033	Lower sprayer assembly	1
92	DW-0001-133	Extractable cup filter	1
93	DW-0018-380	Inner pipe	1
94	DW-0001-132	Nice filter	1
95	DW-0001-135	Filter support	1
96	DW-0001-236	Flat filter	1
97	DW-0001-110	Watershed	1
98	DW-0001-333	Seal for watershed	1
101	DW-0001-153	Hole plug	
103	DW-0001-122	Upper sprayer pipe holder	
104	DW-0001-340	Matching seal	4
105	DW-0001-123	Matching piece	1
106	DW-0001-121	Upper sprayer pipe	1
107	DW-0001-032	Upper sprayer assembly	1
108	DW-0001-150	Cup rack	1
109	DW-0001-125	Basket wheel holder	
110	DW-0001-124	Wheels of upper basket	8

208210000832 complete lid

111	DW-0001-301	Upper basket	1
112	DW-0001-126	Wheels of lower basket	8
113	DW-0001-125	Basket wheel holder	
114	DW-0001-302	Lower basket	1
115	DW-0001-039	Fork basket assembly	1
116	DW-0001-139	Basket guide rear block	
117	DW-0001-138	Basket guide front block	
118	DW-0001-238	Upper basket guide	2
119	W-15-302C	Microswitch	1
120	DW-0001-026	Door lock assembly	1
121	DW-0001-224	Dispenser holder	
122	DW-0026-366	Display PCBA	1
123	DW-0095-176	Plastic handle	1
124	DW-0155-322	Spring	6
125	DW-0155-117	Power button	3
126	DW-0001-144	Salt funnel	1
127	DW-0001-143	Draining hose hanger	1
128	DW-0095-155	Baseboard	1
129	DW-0002-404	Inner door bitument	1
130	DW-0002-404	Inner door bitument	1
131	DW-0002-408	Inner door panel bitument	1
132	DW-0165-361	Wiring	1
133	DW-0001-164	Lower seal holder	1
134	DW-0001-345	Lower seal of inner door	1

Loc 129 : 228210000897 Kick Panel