



















# Baumatic

## Spare parts list for Baumatic model BAF91EG

| Position | Part Number | Description                              | Comment              |
|----------|-------------|------------------------------------------|----------------------|
| 1        | 910588      | PAN SUPPORT BUMPER KIT                   |                      |
| 11       | 202375      | PART FOR BURNER FIXING                   |                      |
| 38       | 306003      | THERMOSTAT CLIP                          |                      |
| 39       | 306002      | SPRING FOR KNOB                          |                      |
| 80       | 504160      | COVER FOR SMALL FLAME SPREADER           |                      |
| 81       | 504161      | COVER FOR MEDIUM BURNER                  |                      |
| 82       | 504162      | COVER FOR RAPID BURNER                   |                      |
| 83       | 504158      | COVER OUT FOR ULTRA RAPID FLAME SPREADER |                      |
| 83       | 504800      | COVER OUT FOR ULTRA RAPID FLAME SPREADER | from 13/12/10        |
| 84       | 504191      | COVER IN FOR ULTRA RAPID FLAME SPREADER  |                      |
| 84       | 504798      | COVER IN FOR ULTRA RAPID FLAME SPREADER  | from 13/12/10        |
| 105      | 202626      | UP SUPPORT FOR AXIAL COOLIN FAN          |                      |
| 106      | 202659      | DOWN SUPPORT FOR AXIAL COOLIN FAN        |                      |
| 117      | 190050      | PROTECTION FOR FAN ASSISTED OVEN         |                      |
| 120      | 101280      | OVEN TRAY                                |                      |
| 138      | 202348      | DISHWARMER BOTTOM                        |                      |
| 160      | 202526      | BRIDLE FOR FIXING GAS VALVES             |                      |
| 166      | 101297      | INSIDE OVEN DOOR                         |                      |
| 176      | 202351      | CARTER MOTORVENTILATOR                   |                      |
| 274      | 202681      | HORIZONTAL VENT                          |                      |
| 311      | 301122      | SCREW 4,2X30                             |                      |
| 312      | 200145      | OVEN GLASS FIXING RING                   |                      |
| 313      | 301073      | SCREW 5MAX10 TCT                         |                      |
| 329      | 309116      | HIGH INSIDE DOOR SPACER                  |                      |
| 385      | 306024      | SPRING FOR SPARK PLUG                    |                      |
| 389      | 301109      | SCREW M5X32 FOR HANDLE                   |                      |
| 392      | 309026      | PART FOR KNOB PROTECTION FIXING          |                      |
| 425      | 415054      | SPARK PLUG 350MM                         |                      |
| 426      | 415057      | SPARK PLUG 700MM                         |                      |
| 428      | 415073      | SPARK PLUG FOR ULTRA RAPID BURNER        |                      |
| 428      | 415102      | SPARK PLUG FOR ULTRA RAPID BURNER        | from 13/12/10        |
| 430      | 415081      | ACCUMULATOR                              |                      |
| 436      | 402090      | BACK FIBER GLASS                         |                      |
| 441      | 404042      | SIDE GRID FOR OVEN                       |                      |
| 442      | 404154      | GRID FOR OVEN                            |                      |
| 443      | 404151      | GRID FOR TRAY                            |                      |
| 444      | 405003      | OVEN DOOR HINGE FIX PART                 |                      |
| 446      | 405039      | OVEN DOOR HINGE M9/D2                    |                      |
| 450      | 409040      | ELECTRONIC PROGRAMMER                    |                      |
| 453      | 411084      | RING GASKET                              |                      |
| 478      | 200430      | DISHWARMER FLAP DOOR                     |                      |
| 561      | 508025      | THERMOCOUPLE MM300                       |                      |
| 562      | 508021      | THERMOCOUPLE MM600                       |                      |
| 565      | 508027      | THERMOCOUPLE MM800                       |                      |
| 566      | 508034      | THERMOCOUPLE ULTRA-RAPID BURNER          |                      |
| 611      | 603025      | MOTOR convec 46mm shaft 220/240V 50/60HZ | see below if shorter |
| 612      | 603021      | COOLING FAN                              |                      |

| Position | Part Number | Description                          | Comment       |
|----------|-------------|--------------------------------------|---------------|
| 613      | 606049      | RESISTENCE 1800W 240V                |               |
| 614      | 606060      | UPPER+GRILL RESISTANCE               |               |
| 615      | 606045      | CIRCULAR HEATER 3000W 240V           |               |
| 621      | 602031      | COMMUTATOR 9+0                       |               |
| 623      | 608018      | OVEN BULB WITH HOLDER                |               |
| 648      | 601965      | TERMINAL SEPARATOR                   |               |
| 649      | 608034      | SMALL WARNING LIGHT                  |               |
| 667      | 602025      | THERMOSTAT                           |               |
| 670      | 504128      | SMALL FLAME SPREADER                 |               |
| 671      | 504129      | MEDIUM FLAME SPREADER                |               |
| 672      | 504130      | RAPID FLAME SPREADER                 |               |
| 673      | 504777      | ULTRA RAPID FLAME SPREADER           |               |
| 673      | 504796      | ULTRA RAPID FLAME SPREADER           | from 13/12/10 |
| 715      | 604072      | DASYCHAIN SWITCH                     |               |
| 760      | 510507      | SMALL BURNER                         |               |
| 761      | 510508      | SEMI RAPID BURNER                    |               |
| 762      | 510509      | RAPID BURNER                         |               |
| 763      | 510708      | ULTRA-RAPID BURNER                   |               |
| 880      | 502217      | GAS VALVE BY PASS 034                |               |
| 881      | 502218      | GAS VALVE BY PASS 036                |               |
| 882      | 502221      | GAS VALVE BY PASS 052                |               |
| 883      | 502223      | GAS VALVE BY PASS 065                |               |
| 917      | 200303      | STAINLESS STEEL SIDE                 |               |
| 929      | 202108      | VERTICAL VENT                        |               |
| 930      | 202214      | FEET SUPPORT                         |               |
| 940      | 405075      | WORK TABLE AND TOP COVER HINGE RIGHT |               |
| 941      | 405076      | WORK TABLE AND TOP COVER HINGE LEFT  |               |
| 943      | 308031      | BUMPER FOR C.I. GRIDS AND DISHWARMER |               |
| 960      | 408074      | CAST IRON PAN SUPPORT 1 BURNER       |               |
| 965      | 408073      | CAST IRON PAN SUPPORT 2 BURNERS      |               |
| 972      | 202360      | WORK TABLE FIXING                    |               |
| 1039     | 4010164     | THERMOSTAT KNOB                      |               |
| 1041     | 4010161     | GAS VALVE KNOB                       |               |
| 1048     | 4010163     | COMMUTATOR KNOB                      |               |
| 1058     | 4010105     | KNOB RING                            |               |
| 1143     | 410532      | RISER                                |               |
| 1406     | 403508      | OVEN HANDLE                          |               |
| 1407     | 406143      | OVEN DOOR GLASS STOPSOL              |               |
| 1409     | 411052      | UNDER GLASS OVEN GASKET              |               |
| 1411     | 411087      | GASKET FOR OVEN FRONT 4 SIDE         |               |
| 1411     | 411088      | GASKET FOR OVEN FRONT ONE SIDE       |               |
| 1415     | 602037      | THERMOREGULATOR                      |               |
| 1421     | 406349      | INTERNAL OVEN GLASS                  |               |
| 1602     | 210595      | CONTROL PANEL                        |               |
| 1614     | 201160      | BACK PANEL                           |               |
| 1615     | 202508      | CONTROL SUPPORT                      |               |
| 1616     | 402169      | FIBER GLASS                          |               |
| 1622     | 608029      | SMALL YELLOW BUD                     |               |
| 1624     | 200319      | WORK TABLE                           |               |
| 1627     | 501872      | GAS COLLECTOR                        |               |
| 1628     | 5010020     | FRONT RIGHT TUBE                     |               |
| 1629     | 501827      | LEFT FRONT TUBE                      |               |
| 1630     | 501833      | RIGHT BACK TUBE                      |               |
| 1631     | 501826      | TUBE FOR LEFT BACK BURNER            |               |
| 1632     | 501828      | CENTRAL TUBE                         |               |

| Position | Part Number | Description                              | Comment             |
|----------|-------------|------------------------------------------|---------------------|
| 1640     | 202223      | CLAMP PROTECTION FOR FLAP DOOR           |                     |
| 1644     | 414044      | FEET                                     |                     |
| 1645     | 414031      | BASE FOR LEGS                            |                     |
| 1661     | 202127      | OVEN PANEL                               |                     |
| 1671     | 101256      | ELECTRIC OVEN PANEL                      |                     |
| 1673     | 101409      | BACK PANEL FOR OVEN                      |                     |
| 1674     | 101115      | OVEN TOP PANEL BLACK                     |                     |
| 1677     | 101423      | FRONT PANEL BLACK M9                     |                     |
| 1685     | 201152      | BACK VENT STACK                          |                     |
| 1705     | 200081      | OVEN GLASS SUPPORT M9/D2                 |                     |
| 2016     | 190040      | OVEN SIDE PANEL BLACK RIGHT              |                     |
| 2130     | 201159      | GRILL PROTECTION                         |                     |
| 4301     | 410540      | RIGHT VERTICAL PROFILE                   |                     |
| 4302     | 410541      | LEFT VERTICAL PROFILE                    |                     |
| 611      | 12590030    | MOTOR convec 33mm shaft 220/240V 50/60HZ | if longer see above |

702    408117    ADAPTER FOR WOK BURNER PAN SUPPORT