




Drwg	Part #	Description	Qty
1	33031001	Top Cover Board	
2	33026001	Guard Board	
3	33313002	tangential cooling fan assembly	1
4	33035001	thermostat switch sensor fixer	1
5	33303006	top oven & grill element	1
6	33314002	motor- rotisserie - NOT APPLICABLE -	na
7	33030002	back cover board	
8	33305002	electrical connection	
9	33304004	power cord	
10	33121002	bottom heat preservation fibre	
11	33315002	motor- fan forced	1
12	33016001	back bracket	
13	33319001	spring	
14	33302002	light assembly (incl Light Globe 25w)	1
14a	33302002G	Light Globe 25w	1
15	33120002	heat preservation fibre	
16	33021001	inner- rail formed in one piece	
17	33024001	lateral bracket	
18	33181001	hinge fixer / carrier	2
19	33803001	door seal	1
20	33001001	back grill guard board	
21	33303002	bottom oven element	1
22	33023001	heat dissipation hole guard board	
23	33003001	bottom grill fixing board	
24	33029001	base board	
25	33171001	spinning lever rack	
26	33224001	enamel pan	1
26a	33170003	trivett for enamel pan	1
27	33223003	spinning lever subassembly	
28	33180001	hinge LH & RH	2
29	33010001	door frame subassembly	
30	33037006	middle glass fixing board	
31	33219001	door frame embedding strip	
32	33014001	panel bottom fixing bracket - Also 34 & 35	2
33	33104001	glass - door middle	1
34	33015006	stainless steel strip on glass A61.A62 ARC logo Also 32 & 35	1
35	33102001	glass - door outer (please affix 33015006) Also 32 & 34	1
35a	33214002	Bush - Plastic bush, Sits in holes in door glass where screws pass thru to attached the door handle	2
36	33103001	glass - door inner	1
37	33190004	handle no.4	1
38	33040001	panel top fixing bracket	

Drwg	Part #	Description	Qty
39	33013001	joint plate	2
40	33170002	Wire shelf - rack alt 33170001	1
41	33217003	door assembling ring	
42	32244008	knob no.2	3
43	33172001	rack handle	1
44	33213001	fasten bolt for switch board	
45	33007001	fascia panel with icons A62.A63	1
46	33101001	switch board	1
47	91034002	single adhesive tape	
48	33301001	function switch - 6 clicks FD6 250v 12a T65	1
49	33307002	timer- electro mechanical DKJ/1 - 120 select Manual OR Timer setting to operate	1
50	33311001	thermostat oven	1
51	33312001	lamp - red indicator lamp	1
52	33032001	right side plate	
53	33033001	left side plate	
54	33214001	inner bladder panel washer	
55	33160001	switch board fastening plate	
56	33004001	timer fixing board	
57	33025001	lateral bracket	
58	33310001	heat dissipation thermostat KLIXON 65'c Cooling Fan	1
59	33308001	overheat protector KLIXON 85'c - Hi Limit	1
60	33028001	exhausting pipe cover board	
61	33027001	exhausting pipe base board	
62	33215001	exhausting chimney	
63	33309002	connecting lead	
	33140001	Wire side wall racks - for wire shelves	2
	33039001	Remove-able/Clean-able Wall Panels	2
a	33131175	Complete Door assy	1

2022.5.18 Control panel is 6 function. Please use 30500100169.