




Model: BAMW2531-P

No	Part No.	Description	QTY
B01	8252010	upper foam cushion	2
B02	8252020	turntable cushion	2
B03	8999803	plastic bag	1
B04	8252040	manual	1
B05	8999505	protection film	1
B06	8999806	plastic bag	1
B07	8252070	lower cushion	2
B08	8252080	carton	1
B09	8252090	cardboard	1
C01	508001	h.v. fuse	1
C02	451202	h.v. diode	1
C03	212100	h.v. capacitor	1
C04	252320	noise filter	1
C05	630925	fan motor	1
C06	230206	lamp	1
C07	180071	thermostat	1
C08	245802	magnetron	1
C09	153021	microswitch	1
C10	151021	microswitch	1
C11	153021	microswitch	1
C12	900954	transformer	1
C13	252131	wiring harness	1
C14	252140	power cord	1
C15	524071	turntable motor	1
C17	250051	p.c. board	1
C19	160191	thermostat	1
C21	231350	heater of convection	1
C23	631325	convection motor	1
C24	231150	heater of grill	1
C26	232260	reactor	1
C76	12	fuse (in noise filter)	1
P03	9252030	fuse socket	1
P04	9252040	capacitor holder	1
P05	9252050	fan shroud	1
P06	9252060	fan blade	1
P09	9252090	washer	1
P10	9252100	shaft	1
P106	9252106	button cover	1
P11	9252110	roller ring	1
P12	9252120	glass tray	1
P13	9252130	splash shield	1
P16	9252160	cavity	1
P17	9252170	label	1
P18	9252180	outer enclosure	1
P19	9252190	heater holder	1
P20	9252200	power cord holder	1
P21	9252210	lamp socket	1
P22	9252220	air duct	1
P23	9252230	microswitch mounting	1
P24	9252241	shock proof rubber	1
P26	9252260	foot	1
P27	9252270	base plate	1
P28	9252280	lower hinge	4
P29	9252290	keyboard (with inlaid)	1
P31	9252310	lever	1
P32	9252320	button spring	1
P33	9252330	button	1
P38	9252380	keypads	1
P39	9252390	knob	1

No	Part No.	Description	QTY
P44	9252440	panel cover board	1
P50	9252500	Heater bracket(upper)	4
P51	9252510	Inner heat insulated	1
P52	9252520	Convectional sponge	1
P53	9252530	Outer heat insulated	1
P54	9252541	M4 skidproof nut	2
P55	9252551	Driving belt	1
P56	9252560	Bearing	1
P57	9252570	Driving wheel	1
P58	9252581	bracket (upper)	1
P59	9252590	Rotational axis	1
P60	9252601	bracket (lower)	1
P61	9252610	Washer	1
P62	9252620	Convectional fan blade	1
P63	9252631	wire fastemer	2
P64	9252641	Lamp bracket	1
P65	9252651	Baking plate	1
P66	9252660	Driving fan blade	1
P67	9252670	Motor bracket	1
P68	9252681	Heat insulated	1
P72	9252721	Right heat insulated plate(	1
P73	9252731	Right heat insulated plate(	1
P75	9252751	spring	1
P76	9252760	lower heater holder(lower)	1
P77	9252770	upper heater holder(lower)	1
P78	9252780	nut of heater	2
P79	9252790	heater holder	2
P80	9252800	knob decoration	1
P81	9252810	display decoration	1
Z02	1252020	door assembly	1