



Entering the Configuration Menu:

- Press and hold down the "*lock"* key (2nd from the right)
- Press each of the first three "+" keys from the right successively, 1, 2, and 3 (whilst pressing the "*lock*" key).
- [C] and [0] are displayed in turns if the key sequence was correct.
- Release the "lock" key.
- Press the "*lock*" key once more and hold until an audible beep is heard.
- [C] is displayed for non configured heating elements and [-] for those that have already been configured.

2

Configuration Process:

- Place a pan on a non configured cooking zone. Press the "+" key on the corresponding touch control.
- After successful configuration, the display changes from [C] to [-].
- Repeat the above steps for any non-configured heating elements in the system

To Exit Configuration Process:

- The configuration process ends automatically after successfully configuring the last heating
- element. The configuration process can be aborted at any tirne by pressing the power key.

Erasing the Configuration:

- Press and hold the "-" key during the configuration process.
- Successful erasing of the process is signalled by a flashing [E] turning into a [C].