




Model: L550SXS

No	Part No.	Description	Qty
1	2102250001	Cabinet	1
2	20122990593	Adjustable foot assembly	2
3	3060100078	Screw of M6*16	6
4	3031400140	Lower door hinge assembly,left	1
5	20122990584	Block of aid-closer,lower	2
6	3060100074	Screw of M6X16	2
7	20122070060	Cover of left hinge,lower	1
8	3031400138	Lower door hinge assembly,right	1
9	20122070059	Cover of right hinge,lower	1
10	20122990488	Return air respirator	1
11	3060100053	Screw ST4.2X13	1
12	20122990629	Thermal head cover	1
13	20122990491	Fan motor bracket	1
14	3029900265	Back rubber gaske of motor	1
15	3059900028 & 3029900272	Motor & Fan blade for motor	
16	3080100059	Front rubber gaske of motor	1
17	20122990495	Electrical installation cover	1
18	3060100053	Screw ST4.2X13	1
20	20122990494	Front cover of Freezer wind tunnel part	1
21	3060100053	Screw ST4.2X13	1
22	20122990493	Screw cap	2
23	20120040030	Lower drawer (purple)	1
24	3060100058	Screw ST4.2X9.5	8
25	20122990484	Guide roller	4
26	20122990483	Left guide I	2
27	20122990485	Rjght guide I	2
28	3070500025	Trademark	1
29	3020500150	Shelf of freezer chamber,upper	5
30	20122990103	Ice Cube Tray	1
31	3020500152	Shelf of refrigerator chamber,upper	5
32	20122990140	Egg Rack	1
33	20122990139	Egg Rack	1
34	3039900190	Compressor cover assembly	1
35	20122050392	Upper rack cover of refrigerator	1
36	20122050409	Upper rack of refrigerator	1
37	20122050408	Lower rack of refrigerator	3
38	20122040294	Crisper drawer,lower	1
39	3039900184	Limit line iron	2
40	20122990583	Block of aid-closer,upper	2
41	3060100048	Screw ST4.2X13	6
42	2200200025	Door gasket,right	1
43	20101160024	Door,right	1
44	3039900292	Door handle	2
45	3050200155	Temperature sensor	2
46	3040300056	Fin Evaperator	1
47	3050700013	Frost heater & fuse	1
48	2700100834	Carton	1
49	3039900181	Fixed slot of heater	1
50	20122090350	Collar,upper	2
51	3060100053	Screw ST4.2X13	1
52	20122990492	Front cover of freezer wind tunnel part	1
55	3060100048	Screw ST4.2X13	1
56	20122990489	Front cover of refrigerator wind tunnel	1
57	2107120007	Foaming parts of refrigerator wind	1
57.1	3071000187	Refrigerator wind foam parts,upper	1
57.2	3071000188	Refrigerator wind foam parts,lower	1
57.3	3059900027	Damper motor of refrigerator wind	1
58	3060100055	Screw ST4.2X16	4
59	20122990482	Cover plate of fixed seat	4

No	Part No.	Description	Qty
60	20122010104	Cover of ceiling light	2
61	3050400018	Ceiling light	2
62	20122080154	Cover of right hinge,upper	1
63	3031400215	Upper door hinge assembly,right	1
64	3031400214	Upper door hinge assembly,left	1
65	20122080153	Cover of left hinge,upper	1
66	3060100017	Screw of M5*16	6
67	3050300027	Control board	1
68	3039900180	Cover of control board	1
69	20122050407	Left rack(purple)	4
70	3040500022	Drier filter (for R600a)	1
71	3040600005	Process tube	1
72	2200200026	Door gasket,left	1
73	20101160023	Door,left	1
74	3060100040	Screw of 2.5*9.5	2
75	3050300039	Electronic board	1
76	3029900328	Cover of electronic board	1
77	3060100048	Screw ST4.2X13	2
78	20122990481	Drain pan	1
79	20114010065	Evaporative condenser	1
80	3050200094	Earthing wire of compressor	1
81	3060100078	Screw of M6*16	4
82	20122080097	Compressor base support	1
83	3050100125	Power supply cord plug	1
84	3040100252	Compressor parts	1
85	20114070026	Connecting tube	1
86	3059900021	Door switch	2