




Model: ECFR688W

No	Part No.	Description	Qty	Comments
2	2208101161	Cover of door hinge,lower	4	
4	2208200021	Cover of door hinge,upper	4	
5	2301400008	Door hinge assembly	4	
6	2208100371	Cover of the wire	1	
8	2150130365	Door	2	
8.1	2200200099	Door gasket	1	
8.2	2500900009	LED light assembly	1	
10	2301300031	Iron of centre still	1	
11	2500700030	Compensatory heater	1	
12	2701000190	Foam of centre still	1	
13	2208100454	Cover of centre still	1	
15	20122990706	Ice scraper	1	
17	2305100016	Food basket	2	
18	20122990670	Door handle,Cover	2	
19	20122990671	Door handle,Seat	2	
20	2208100045	Decorative cover of door handle	2	
21	2208101719	Light wire cover	2	
23	2207700242	Drain-pipe plug	1	
24	20122990649	Drain-pipe decorative cover	1	
25	3039900278	Direction wheel	2	
26.1	2207100086	Controller Panel	1	
26.2	2500300311	Electrical Controller Board	1	
26.3	2209100234	Film Of Controller Panel	1	
27	2208200023	Cover of controlor	1	
28	2207700023	Castor wheel	4	
29	2500800855	Frequency conversion main control assembly	1	
30	3039900352	Wire connector	2	
31	2500100078	Power supply cord plug	1	
34	3050200094	Earthing wire of compressor	1	
35	2500200717	Connecting wire of compressor	1	
35	2500200202	Connecting wire of compressor	1	
36	2304510006	Compressor base support	1	
41	3040600005	Process tube	1	
42	2400100423	Compressor	1	
43	2305700018	Support of the fan	1	
45	2501000004	Freezer fan parts	1	
46	2400400002	Condenser for compressor	1	
47	2400500003	Connecting tube	1	
50	2400500027	Drier filter	1	
51	2207700090	Cover of compressor	1	
52	2208200106	Cover of the wire	1	