




No	Part No.	Description	Qty
1	33303032	fan element	1
2	33302002	lanmp	2
3	33315002	circulation fan subassembly	1
4	33314002	electric rotating machinery	1
5	33006028	air deflector	1
6	33304010	power cord	1
7	33305002	wire fixer	1
8	33006073 / 33006074	Duct baffle	1
9	33030017	back cover board	1
10	33313027	cooling fan subassembly	1
11	33120009	bottom heat preservation fibre	1
12	33016006	back bracket	1
13	33140006	telescope rail support	2
14	33120009	heat preservation fibre	1
15	33141002	rail support fixed axis	2
16	33001008	back grill guard board	1
17	33005008	hinge fixer	2
18	33018054	inner panel	1
19	33171002	spinning lever rack gear box please order 30401200001	1
20	33223005	spinning lever	1
21	33223006	spinning lever subassembly	1
22	33170010	wire rack	2
23	33018053	support	1
24	33303033	buttom grill	1
25	33003003	buttom grill fixing plate	1
26	33016005	board	1
27	33029007	shell buttom board	1
28	33016007	shell buttom board support	1
29	33300025	timer	1
30	33312001	indicator light	1
31	33311007	thermostat switch	1
32	33301002	function switch	1
33	33006002	switch fixing plate	1
34	33006001	switch connecting plate	2
35	33101319	control panel	1
36	33007154	switch board decorative board	1
37	33213001	switch drawbolt	2
38	32244025	knob	2
39	33180011	hinge subassembly	2
40	33103007	inner glass	2
41	33192001		3
42	33010019	door frame	1
43	33225004	center glass fixed block	4
44	33104009	middle glass	1
45	33014001	fixing plate	3
46	833102159TB-OLD	outer glass	1

Old outer glass: 833102159TB-OLD, having many clips around the sides
New outer glass: 833102159TB, no clips

No	Part No.	Description	Qty
47	33015270	dalle for appearance board	1
48	33190014	handle no 9	1
49	33214002	handle gasket	2
50	33006012	handle fixing plate	2
51	33014006	appearance board fixing mount	3
52	33193001	buckle	5
53	33160001	support	2
54	33170012	support	1
55	33018051	support	1
56	33224007	dish collector	1
57	33018052	support	1
58	33018050	support	1
59	33058023	inner assembly	1
60	33035001	thermostat switch sensor fixer	2
61	33303034	top grill	1
62	33032005	board	1
63	33033006	board	1
64	33170009	handle	2
65	33029008	support connecting plate	2
66	33016004	lower platen	1
67	33215006	aiutage	1
68	33031008	cover board	1
69	33310003	thermostat-45°C	1
70	33308003	over heat protector 95°C	1
	PA210044000	Oven Door Seal	
	33131940TB	Complete Door	