



QUICK START GUIDE - MUST READ



Carefully weigh & measure ingredients.



Follow method as per recipe instructions.



Recipes that include flour, follow recipe method before adding.



Stir ingredients before putting on the lid.



Clean thoroughly after each use.

If your soup maker cuts out during its cycle, it could be due to ingredients sticking to the heating plate.

Discard ingredients, clean your soup maker thoroughly and start again, ensuring the method is followed correctly and taking note of the advice given above.



QUICK START GUIDE - MUST READ



**Guess ingredient
weights & volumes**



**Add non-specified
ingredients**



**Overfill the soup maker
(see fill mark)**



**Add flour without
following recipe
method.**



**Allow food to adhere
to the heating plate**